

In this first box we're just simply importing in all of the modules that are being used and ensuring we are in the right directory to get our calibration files.

```
In [1]: import numpy as np
import matplotlib.pyplot as plt
from astropy.io import fits
from scipy import stats
import os

cwd = os.getcwd()
if cwd[-5:] != "Lab_3":
    os.chdir("/Users/efrainmartinez/Downloads/SBU/SBU_Spring_2024_Semester/AST")
```

In this next box we're importing in all of the calibration files we're going to need for data reduction. We have dark frames specifically for merak (actually taken with a 2 min exposure) that we can also use for the flat fields and the lamp spectrum, and then the dark frames we use for the galaxies. We are also importing the flat field images so that we can subtract any dark current from it.

```
In [2]: # Importing the dark frames that were taken for Merak

two_min_dark_prefix = "lab_3_dark_5_min.0000000"
two_min_dark_suffix = ".DARK.FIT"
two_min_dark_data = []
two_min_start = 0
two_min_end = 4

for i in range(two_min_start, two_min_end+1, 1):
    filename = two_min_dark_prefix + str(i) + two_min_dark_suffix
    list = fits.open('calibration_images/'+filename)
    image_data = list[0].data
    two_min_dark_data.append(image_data)

# Importing the dark frames that were taken for the galaxies and will be used
gal_dark_prefix = "lab_3_dark_25_min.0000000"
gal_dark_suffix = ".DARK.FIT"
gal_dark_data = []
gal_start = 0
gal_end = 1

for i in range(gal_start, gal_end+1, 1):
    filename = gal_dark_prefix + str(i) + gal_dark_suffix
    list = fits.open('calibration_images/'+filename)
    image_data = list[0].data
    gal_dark_data.append(image_data)

# lamp_data = []
# with fits.open('calibration_images/lab_3_ne_lamp.00000000.FIT') as file:
#     plt.imshow(file[0].data, cmap='gray', vmax=9000)
#     plt.colorbar()
#     lamp_data.append(file[0].data)

# Importing the flat fields that were taken for our observations (same for all)
flat_prefix = "lab_3_flat_2_min.0000000"
```

```

flat_suffix = ".FIT"
flat_data = []
flat_start = 0
flat_end = 3

for i in range(flat_start, flat_end+1, 1):
    ind = str(i)
    filename = flat_prefix + str(i) + flat_suffix
    list = fits.open('calibration_images/'+filename)
    image_data = list[0].data
    flat_data.append(image_data)

```

Here we're just calculating the master dark frames for the 2 min and the 25 min dark frames. We're using the mean here rather than the median since there are not that many points to work with.

In [3]: *# Calculating the master dark frames for Merak and the Galaxies*

```

two_min_master_dark = np.mean(two_min_dark_data, axis=0)
gal_master_dark = np.mean(gal_dark_data, axis=0)

```

In this box we're importing in all of the science images taken. Rather than having separate sections to import in each set of images separately, we are utilizing lists to open specified files in specified directories. We save each set of images within the list `total_data`, with each index representing each group of images. So `total_data[0]` refers to the merak images, and `total_data[0][0]` refers to the first image in the group of merak images.

In [4]:

```

names = ["lab_3_merak_2_mins.0000000", "lab_3_m51_25_min.0000000", "lab_3_m82_25_min.0000000", "lab_3_lamp_10_min.0000000", "lab_3_sky_10_min.0000000"]
folder_names = ["merak_images", "m51_images", "m82_images", "calibration_images"]

starts = [0, 1, 0, 0, 3]
ends = [4, 3, 2, 0, 5]
image_end = ".FIT"
melark_data = []
m51_data = []
m82_data = []
lamp_data = []
sky_data = []
total_data = [melark_data, m51_data, m82_data, lamp_data, sky_data]

j = 0
for image_prefix in names:
    for i in range(starts[j], ends[j]+1, 1):
        filename = image_prefix + str(i) + image_end
        list = fits.open(folder_names[j]+'/'+filename)
        image_data = list[0].data
        total_data[j].append(image_data)
    j += 1

# print(min(total_data[1][0].flatten()))
# x = np.linspace(0, len(total_data[1][0].flatten()), num=len(total_data[1][0].flatten()))
# plt.plot(x, total_data[1][0].flatten())

# for i in range(len(total_data[1])):
#     x = np.linspace(0, len(total_data[1][i].flatten()), num=len(total_data[1][i].flatten()))
#     plt.plot(x, total_data[1][i].flatten())

```

```
# plt.show()
```

Now we're taking our data and subtracting out the dark current for each image. The merak and lamp images correspond to `total_data[0]` and `total_data[3]`. So when we subtract from those in our loop we ensure we're using the two minute dark frame, while for the rest we subtract the 25 minute dark frame, i.e. `gal_master_dark`. We save the calibrated data in the list `calib_totals`.

We then separate `calib_totals` into the respective groups and also subtract the dark current from our flat field images as well. We also create a "master sky" image by using both the mean values and the median values. For all of the values in the two master sky images, if the value is less than 0.0 we set the value equal to the mean/median value. **We haven't done this for the individual science images yet, and we are unsure if we should be doing that or not.**

Finally we subtract the sky images from our calibrated sky images, using both the mean sky image and the median sky image separately.

```
In [5]: calib_totals = []
merak_final = []
m51_final = []
m82_final = []
lamp_final = []
sky_final = []

for j in range(0, 5):
    for i in range(0, len(total_data[j])):
        if j == 0 or j == 3:
            calib_totals.append(total_data[j][i]-two_min_master_dark)
        else:
            calib_totals.append(total_data[j][i]-gal_master_dark)

for i in range(0, len(calib_totals)):
    for j in range(0, 255):
        for k in range(0, 765):
            if calib_totals[i][j][k] < -500.:
                calib_totals[i][j][k] = np.median(calib_totals[i].flatten())

merak_final = calib_totals[0:5]
m51_final = calib_totals[5:8]
m82_final = calib_totals[8:11]
lamp_final = calib_totals[11:12]
sky_final = calib_totals[12:]
flat_final = flat_data - two_min_master_dark

sky_median = [np.median(sky_final, axis=0)]
sky_mean = [np.mean(sky_final, axis=0)]
total_sky_median = np.median(sky_median[0].flatten())
total_sky_mean = np.mean(sky_mean[0].flatten())

for i in range(0, 255):
    for j in range(0, 765):
        if sky_median[0][i][j] < 0.0:
```

```

        sky_median[0][i][j] = total_sky_median
    if sky_mean[0][i][j] < 0.0:
        sky_mean[0][i][j] = total_sky_mean

merak_final_med = [merak_final[x] - (sky_median[0])/12.5 for x in range(0, len(
merak_final_mean = [merak_final[x] - (sky_mean[0])/12.5 for x in range(0, len(
m51_final_med = [m51_final[x] - sky_median for x in range(0, len(m51_final))]
m51_final_mean = [m51_final[x] - sky_mean for x in range(0, len(m51_final))]
m82_final_med = [m82_final[x] - sky_median for x in range(0, len(m82_final))]
m82_final_mean = [m82_final[x] - sky_mean for x in range(0, len(m82_final))]

# print(min(m51_final_med[0].flatten()))

# x = np.linspace(0, len(two_min_master_dark.flatten()), num=len(two_min_maste
# plt.plot(x, two_min_master_dark.flatten())
# plt.title("2 Minute Dark Frame Counts")
# plt.show()
# plt.title("Final Data for one m51 Image")
# plt.plot(x, m51_final_med[0].flatten())

# titles = ["Merak", "M51", "M82", "Lamp", "Sky"]
# for i in range(0, 15):
#     if i in range(0, 5):
#         k = 0
#     elif i in range(5, 8):
#         k=1
#     elif i in range(8, 11):
#         k=2
#     elif i == 11:
#         k=3
#     elif i >= 12:
#         k=4
#     title = titles[k]
#     x = np.linspace(0, len(calib_totals[i].flatten()), num=len(calib_totals[
#     plt.plot(x, calib_totals[i].flatten())
#     plt.title(title)
#     plt.show()

```

Now we're switching directories into our **calibrated\_fits\_files** directory where we will be putting our calibrated files. We once again do this through the use of lists.

```

In [6]: cwd = os.getcwd()
if cwd[-25:] != "calibrated_fits_files":
    os.chdir("/Users/efrainmartinez/Downloads/SBU/SBU_Spring_2024_Semester/AST
    cwd = os.getcwd()
target_names = ["merak_med.00", "merak_mean.00", "m51_med.00", "m51_mean.00",
data = [merak_final_med, merak_final_mean, m51_final_med, m51_final_mean, m82_
j=0
if os.path.exists("merak_med.000.FIT") != True:
    for image_prefix in target_names:
        image_suffix = ".FIT"
        for i in range(0, len(data[j])):
            hdu = fits.PrimaryHDU(data[j][i])
            filename = image_prefix + str(i) + image_suffix
            hdu.writeto(filename, overwrite=True)
        j += 1

# for j in range(0, len(data)):
#     for i in range(0, len(data[j])):


```


```
# x = np.linspace(0, len(data[j][i].flatten()), num=len(data[j][i].fla
# plt.plot(x, data[j][i].flatten())
# plt.show()
```

We're just using this to plot images to see how they look after we saved them.

```
In [7]: with fits.open('m51_mean.001.FIT') as file:
        data = file[0].data
        flat_data = data.flatten()
        x = np.linspace(0, len(flat_data), num=len(flat_data))
        plt.plot(x, flat_data)
        plt.show()

with fits.open('m51_mean.002.FIT') as file:
    data = file[0].data
    flat_data = data.flatten()
    x = np.linspace(0, len(flat_data), num=len(flat_data))
    plt.plot(x, flat_data)
```





## 50 um Flat Fields

Flat fields for 50um slit, used for galaxy spectra.


```
In [8]: from astropy.io import fits
import matplotlib.pyplot as plt
import numpy as np

os.chdir("/Users/efrainmartinez/Downloads/SBU/SBU_Spring_2024_Semester/AST443/I

spectra_image = fits.open('calibrated_fits_files/flat.000.FIT')

data = spectra_image[0].data
plt.imshow(data, cmap='gray', vmax = 20000)
plt.colorbar()
plt.title('Full Spectrum Columns')
```


```
Out[8]: Text(0.5, 1.0, 'Full Spectrum Columns')
```



In [9]: *# Crop data to only include the top band (50um)*

```
crop = data[30:100,:]
print(crop.shape)
plt.imshow(crop,cmap='gray',vmax = 20000)
plt.title(r'50$\mu$m Slit Crop')
print(crop.size)
```

```
(70, 765)
53550
```



In [10]: flat\_list = []

```
# find and open the Flat Fields and store them all in one list
file_prefix = "flat.00"
file_end = ".FIT"
pixel_data = [None]*4

for i in range(0, 4, 1):
    filename = file_prefix + str(i) + file_end
    print(filename)
    list = fits.open('../Lab_3/calibrated_fits_files/'+filename)
    image_data = list[0].data
    pixel_data[i] = image_data[30:100,:]

# open a 2d list to store median values
median_values = np.zeros((70, 765))
```


```
# run through and calculate the median value for each pixel
for i in range(0, 70):
    for j in range(0, 765):
        values = [pixel_data[x][i][j] for x in range(0,4)]
        median_values[i][j] = np.median(values)
```

```
flat.000.FIT
flat.001.FIT
flat.002.FIT
flat.003.FIT
```

```
In [11]: # Calculate the 1D flat field values by averaging along the y-axis
flat_field_1d = np.mean(median_values, axis=0)

# Plotting the 1D flat field values against pixel positions along the dispersion axis
dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, flat_field_1d)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('1D Flat Field Values')
plt.title('1D Flat Field Across Dispersion Axis')
plt.grid(True)
plt.show()
```



```
In [12]: from astropy.modeling import models, fitting

# Pixel positions along the dispersion axis
dispersion_axis = np.arange(765) #765 is the length of the dispersion axis

# Initialize various polynomial models for fitting
```



```

first_order = models.Polynomial1D(degree=1)
second_order = models.Polynomial1D(degree=2)
fifth_order = models.Polynomial1D(degree=5)
tenth_order = models.Polynomial1D(degree=10)
thirty_order = models.Polynomial1D(degree=30)

# Initialize a fitting algorithm
fitter = fitting.LinearLSQFitter()

# Fit the models to the 1D flat-field spectrum
first_fit = fitter(first_order, dispersion_axis, flat_field_1d)
second_fit = fitter(second_order, dispersion_axis, flat_field_1d)
fifth_fit = fitter(fifth_order, dispersion_axis, flat_field_1d)
tenth_fit = fitter(tenth_order, dispersion_axis, flat_field_1d)
thirty_fit = fitter(thirty_order, dispersion_axis, flat_field_1d)

# Generate the fits using the fitted model
first_fit_curve = first_fit(dispersion_axis)
second_fit_curve = second_fit(dispersion_axis)
fifth_fit_curve = fifth_fit(dispersion_axis)
tenth_fit_curve = tenth_fit(dispersion_axis)
thirty_fit_curve = thirty_fit(dispersion_axis)


# Plot the original flat-field and the fitted curves
plt.plot(dispersion_axis, flat_field_1d, label='Original Flat Field')
plt.plot(dispersion_axis, first_fit(dispersion_axis), label='First Order Fit',
plt.plot(dispersion_axis, second_fit(dispersion_axis), label='Second Order Fit',
plt.plot(dispersion_axis, fifth_fit(dispersion_axis), label='Fifth Order Fit',
plt.plot(dispersion_axis, tenth_fit(dispersion_axis), label='Tenth Order Fit',
plt.plot(dispersion_axis, thirty_fit(dispersion_axis), label='Thirty Order Fit

plt.xlabel('Pixel Positions along Dispersion Axis')
plt.ylabel('1D Flat Field Values')
plt.title('Fitted Curve for Flat-Field Normalization')
plt.legend()
plt.grid(True)
plt.show()

# Divide the 2D flat-field by the fits to obtain the normalized flat-field
first_normalized_flat_field = median_values / first_fit_curve
second_normalized_flat_field = median_values / second_fit_curve
fifth_normalized_flat_field = median_values / fifth_fit_curve
tenth_normalized_flat_field = median_values / tenth_fit_curve
thirty_normalized_flat_field = median_values / thirty_fit_curve


```

WARNING: The fit may be poorly conditioned  
[astropy.modeling.fitting]



```
In [13]: plt.imshow(crop, cmap='gray', vmax = 20000)
plt.title('Original')
plt.colorbar()
```

```
Out[13]: <matplotlib.colorbar.Colorbar at 0x7f79b0539490>
```



```
In [14]: plt.imshow(thirty_normalized_flat_field, cmap='gray', vmax = 1.5)
plt.title('Thirty Order Fit')
plt.colorbar()
```

```
Out[14]: <matplotlib.colorbar.Colorbar at 0x7f79b0159fd0>
```



## 25 um Flat Fields

Used for Merak analysis

```
In [15]: flat25_list = []

# find and open the Flat Fields and store them all in one list
file_prefix = "flat.00"
file_end = ".FIT"
pixel_data = [None]*4

for i in range(0, 4, 1):
    filename = file_prefix + str(i) + file_end
    print(filename)
    list = fits.open('../Lab_3/calibrated_fits_files/'+filename)
    image_data = list[0].data
    pixel_data[i] = image_data[110:195,: ]

# open a 2d list to store median values
median25_values = np.zeros((75, 765))


# run through and calculate the median value for each pixel
for i in range(0, 75):
    for j in range(0, 765):
        values = [pixel_data[x][i][j] for x in range(0,4)]
        median25_values[i][j] = np.median(values)
```

```
flat.000.FIT
flat.001.FIT
flat.002.FIT
flat.003.FIT
```

```
In [16]: # Calculate the 1D flat field values by averaging along the y-axis
flat25_field_1d = np.mean(median25_values, axis=0)

# Plotting the 1D flat field values against pixel positions along the dispersion axis
dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, flat25_field_1d)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('1D Flat Field Values')
plt.title('1D Flat Field Across 25um Slit')
plt.grid(True)
plt.show()
```



```
In [17]: from astropy.modeling import models, fitting

# Pixel positions along the dispersion axis
dispersion_axis = np.arange(765) #765 is the length of the dispersion axis

# Initialize various polynomial models for fitting
first_order = models.Polynomial1D(degree=1)
second_order = models.Polynomial1D(degree=2)
fifth_order = models.Polynomial1D(degree=5)
tenth_order = models.Polynomial1D(degree=10)
thirty_order = models.Polynomial1D(degree=30)
```

```
# Initialize a fitting algorithm
fitter = fitting.LinearLSQFitter()


# Fit the models to the 1D flat-field spectrum
first25_fit = fitter(first_order, dispersion_axis, flat25_field_1d)
second25_fit = fitter(second_order, dispersion_axis, flat25_field_1d)
fifth25_fit = fitter(fifth_order, dispersion_axis, flat25_field_1d)
tenth25_fit = fitter(tenth_order, dispersion_axis, flat25_field_1d)
thirty25_fit = fitter(thirty_order, dispersion_axis, flat25_field_1d)

# Generate the fits using the fitted model
first25_fit_curve = first25_fit(dispersion_axis)
second25_fit_curve = second25_fit(dispersion_axis)
fifth25_fit_curve = fifth25_fit(dispersion_axis)
tenth25_fit_curve = tenth25_fit(dispersion_axis)
thirty25_fit_curve = thirty25_fit(dispersion_axis)

# Plot the original flat-field and the fitted curves
plt.plot(dispersion_axis, flat25_field_1d, label='Original Flat Field')
plt.plot(dispersion_axis, first25_fit(dispersion_axis), label='First Order Fit')
plt.plot(dispersion_axis, second25_fit(dispersion_axis), label='Second Order Fit')
plt.plot(dispersion_axis, fifth25_fit(dispersion_axis), label='Fifth Order Fit')
plt.plot(dispersion_axis, tenth25_fit(dispersion_axis), label='Tenth Order Fit')
plt.plot(dispersion_axis, thirty25_fit(dispersion_axis), label='Thirty Order Fit')


plt.xlabel('Pixel Positions along Dispersion Axis')
plt.ylabel('1D Flat Field Values')
plt.title('Fitted Curve for Flat-Field Normalization')
plt.legend()
plt.grid(True)
plt.show()

# Divide the 2D flat-field by the fits to obtain the normalized flat-field
first25_normalized_flat_field = median25_values / first25_fit_curve
second25_normalized_flat_field = median25_values / second25_fit_curve
fifth25_normalized_flat_field = median25_values / fifth25_fit_curve
tenth25_normalized_flat_field = median25_values / tenth25_fit_curve
thirty25_normalized_flat_field = median25_values / thirty25_fit_curve
```



```
In [18]: plt.imshow(thirty25_normalized_flat_field,cmap='gray',vmax=1.5)
plt.title('Thirty Order Fit 25um Slit')
plt.colorbar()
```

```
Out[18]: <matplotlib.colorbar.Colorbar at 0x7f79b2f9bca0>
```



# Arc Lamp


Below is the full arc lamp spectra:

```
In [19]: from astropy.io import fits
import matplotlib.pyplot as plt
import numpy as np

spectra = fits.open('calibrated_fits_files/neon.000.FIT')

spectra_data = spectra[0].data
plt.imshow(spectra_data, cmap='gray', vmin = -10, vmax = 800)
plt.colorbar()
plt.title('Arc Lamp Spectra')
```


Out[19]: Text(0.5, 1.0, 'Arc Lamp Spectra')



```
In [20]: spectra_crop = spectra_data[30:100,:]
print(spectra_crop.shape)
plt.imshow(spectra_crop, cmap='gray', vmax=8800)
plt.title(r'Crop of 50$\mu$m Slit')
```

(70, 765)


Out[20]: Text(0.5, 1.0, 'Crop of 50 $\mu$ m Slit')



```
In [21]: #Apply normalized flat field to arc lamp spectrum using the first order fit
normal = spectra_crop / thirty_normalized_flat_field

plt.imshow(normal, cmap='gray', vmax= 9000)
plt.title(r'Normalized Flat Field Applied to 50$\mu$m Slit')
plt.colorbar()
```

Out[21]: <matplotlib.colorbar.Colorbar at 0x7f79b3543eb0>




## Dispersion Axis: Pixel --> Wavelength

```
In [22]: # Calculate the 1D spectra by averaging along the y-axis
flat_field = np.mean(normal, axis=0)

# Plot the 1D pixel counts against pixel positions along the dispersion axis
dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, flat_field)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('Counts')
plt.title('1D Ne Spectra')
plt.grid(True)
plt.show()
```





```
In [23]: import numpy as np
import matplotlib.pyplot as plt
from scipy.signal import find_peaks
from astropy.modeling import models, fitting

# Find peaks corresponding to known_wavelengths
peaks, _ = find_peaks(flat_field, height=35)

# Define the pixel positions of identified peaks

peaks = peaks.tolist()
# peaks.pop(10) # Remove double peak around pixel 540
pixel_positions = peaks

# Known Neon spectrum emission lines provided by https://www.atomtrace.com/elements/neon
known_wavelengths = [6217.28, 6266.49, 6304.79, 6334.43, 6382.99, 6402.25, 6500.00]

# Define the model for fitting
linear_model = models.Polynomial1D(degree=1)

# Perform the fitting
fitter = fitting.LinearLSQFitter()
best_fit = fitter(linear_model, pixel_positions, known_wavelengths)

# Plot the data and the best-fit line
plt.plot(pixel_positions, known_wavelengths, 'o', label='Emission Lines')
plt.plot(pixel_positions, best_fit(pixel_positions), label='Best Fit')
plt.xlabel('Pixel Position')
plt.ylabel('Wavelength (nm)')
```

```
plt.title('Wavelength Calibration')
plt.grid(True)
plt.legend()
```

```
# Display the fit parameters
print(best_fit)
plt.show()
```

Model: Polynomial1D

Inputs: ('x',)

Outputs: ('y',)

Model set size: 1


Degree: 1

Parameters:

c0

c1

-----  
6186.767850650794 0.9813911306273252




```
In [24]: # Using best fit equation, adjust x-axis from pixels to nm
pixels = np.arange(765)
wavelength_axis = 6186.767850650795 + 0.9813911306273253*pixels

plt.plot(wavelength_axis, flat_field)
plt.xlabel(r'Wavelength ($\AA$)')
plt.ylabel('Counts')
plt.title('Neon Emission Line Spectra')

#Add labels for stronger emission lines
#plt.text(584,530,'588nm',color='red',alpha=1.0,fontsize=9.5)
```

```
plt.grid(True)
plt.show()
```




## Merak

```
In [25]: from astropy.io import fits
import matplotlib.pyplot as plt
import numpy as np

#One of the Merak FITS
merak_spec = fits.open('calibrated_fits_files/merak_mean.000.FIT', vmin = -10, \

merak_spec_data = merak_spec[0].data
plt.imshow(merak_spec_data, cmap='gray')
plt.colorbar()
plt.title('Merak Spectra')
```


```
Out[25]: Text(0.5, 1.0, 'Merak Spectra')
```



```
In [26]: #Crop data to only include the middle band (25um)

merak_crop = merak_spec_data[110:195,:]
print(crop.shape)
plt.imshow(merak_crop,cmap='gray',vmin = -10, vmax = 1000)
plt.title(r'25 $\mu$ m Slit Crop')
print(crop.size)

(70, 765)
53550
```



```
In [27]: merak_data = []

# find and open the Flat Fields and store them all in one list
file_prefix = "merak_mean.00"
file_end = ".FIT"
pixel_data = [None]*5

for i in range(0, 5):
    filename = file_prefix + str(i) + file_end
    print(filename, i)
    list = fits.open('../Lab_3/calibrated_fits_files/'+filename)
    image_data = list[0].data
    pixel_data[i] = image_data[110:195,:]

# open a 2d list to store median values
```

```

merak_median_values = np.zeros((75, 765))

# run through and calculate the median value for each pixel
for i in range(0, 75):
    for j in range(0, 765):
        values = [pixel_data[x][i][j] for x in range(0,5)]
        merak_median_values[i][j] = np.median(values)

merak_mean.000.FIT 0
merak_mean.001.FIT 1
merak_mean.002.FIT 2
merak_mean.003.FIT 3
merak_mean.004.FIT 4

```

```


In [28]: #Apply normalized flat field to arc lamp spectrum using the first order fit
science_merak = merak_median_values / thirty25_normalized_flat_field

# Calculate the 1D spectra by averaging along the y-axis
merak_tot = np.mean(science_merak, axis=0)

# Plot the 1D pixel counts against pixel positions along the dispersion axis
dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, merak_tot)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('Counts')
plt.title('1D Merak Pixel Spectra')
plt.grid(True)
plt.show()

```



```

In [29]: merak_og = merak_tot[:]
for i in range(0, 2):
    # Using best fit equation, adjust x-axis from pixels to nm
    plt.plot(wavelength_axis, merak_tot)
    plt.xlabel(r'Wavelength ($\AA$)')
    plt.ylabel('Counts')
    plt.title('Merak Emission Line Spectra')

    #Add labels for stronger emission lines
    #plt.text(584,530,'588nm',color='red',alpha=1.0,fontsize=9.5)

    wavelength_axis_og = wavelength_axis[:]
    if str(type(merak_tot)) != "<class 'list'>":
        merak_tot = merak_tot.tolist()
        wavelength_axis = wavelength_axis.tolist()

    start = 0
    end = 60
    start1 = end
    end1 = 240
    start2 = end1
    end2 = 360
    start3 = end2 + 65
    end3 = 712
    start4 = end3

    midstart = end2
    midend = start3

    s1 = 360
    e1 = 425
    s2 = 687
    e2 = 712

    # del merak_tot[s2:e2]
    # del wavelength_axis[s2:e2]



    m1 = (merak_tot[start3] - merak_tot[end2-1]) / (wavelength_axis[start3] - wavelength_axis[end2-1])
    b1 = merak_tot[end2-1]
    y_line1 = [m1*(x-wavelength_axis[end2-1]) + b1 for x in np.linspace(wavelength_axis[start3], wavelength_axis[end2-1], 100)]
    merak_tot[s1:e1] = y_line1[:]

    m2 = (merak_tot[e2-1] - merak_tot[s2]) / (wavelength_axis[e2-1] - wavelength_axis[s2])
    b2 = merak_tot[s2]
    y_line2 = [m2*(x-wavelength_axis[s2]) + b2 for x in np.linspace(wavelength_axis[s2], wavelength_axis[e2-1], 100)]
    merak_tot[s2:e2] = y_line2[:]

    # plt.plot(wavelength_axis[s2:e2], merak_tot[s2:e2], c='blue')
    plt.plot(wavelength_axis[start:end], merak_tot[start:end], c='r')
    plt.plot(wavelength_axis[start1:end1], merak_tot[start1:end1], c='orange')
    plt.plot(wavelength_axis[start2:end2], merak_tot[start2:end2], c='green')
    plt.plot(wavelength_axis[start3:end3], merak_tot[start3:end3], c='purple')
    plt.plot(wavelength_axis[start4:], merak_tot[start4:], c='blue')
    plt.plot(wavelength_axis[midstart:midend], merak_tot[midstart:midend], c='black')
    plt.plot(wavelength_axis[s2:e2], merak_tot[s2:e2], c='black')

```

```
plt.grid(True)  
plt.show()
```



```

In [30]: from scipy.optimize import curve_fit
import csv

def three(x, a, b, c, d):
    return a*(x)**3 + b*(x)**2 + c*(x) + d

def four(x, a, b, c, d, e):
    return a*(x)**4 + b*(x)**3 + c*(x)**2 + d*(x) + e

def quad(x, a, b, c):
    return a*((x)**2) + b*(x) + c

total_points = []
xplot = []
yplot = []
x_nums = [wavelength_axis[start:end], wavelength_axis[start1:end1], wavelength_axis[midstart:midend], wavelength_axis[start3:end3], wavelength_axis[start4:end4]]
y_nums = [merak_tot[start:end], merak_tot[start1:end1], merak_tot[start2:end2], merak_tot[start3:end3], merak_tot[start4:end4]]

for i in range(0, 6):

    xs = x_nums[i]
    ys = y_nums[i]

    if i == 2 or i == 4:
        param, cov = curve_fit(four, xs, ys)
        a, b, c, d, e = param

        nums = [four(x, a, b, c, d, e) for x in xs]

    elif i == 5:
        param, cov = curve_fit(quad, xs, ys)
        a, b, c = param
        nums = [quad(x, a, b, c) for x in xs]
    elif i == 3:
        nums = ys
    else:
        param, cov = curve_fit(three, xs, ys)
        a, b, c, d = param

        nums = [three(x, a, b, c, d)+3 for x in xs]

    for x_val, y_val in zip(xs, ys):
        xplot.append(x_val)
        yplot.append(y_val)
    for values in nums:
        total_points.append(values)


plt.plot(wavelength_axis_og, merak_og, color="orange")
plt.plot(xplot, total_points, c='blue')

header = ['wavelength', 'fit numbers']
data_vals = zip(xplot, total_points)

with open('sensitivity_nums.csv', 'w') as file:
    writer = csv.writer(file)
    writer.writerow(header)
    writer.writerows(data_vals)

```





In [31]: *#Some old code I made a while ago for fun, see <https://github.com/brady-ryan/p>*

```
import numpy as np
import matplotlib.pyplot as plt

h = 6.626e-34
c = 3.0e+8
k = 1.38e-23
i = 620
j = 700

class Planck:

    def __init__(self,T,name):
        self.T = T
        self.name = name
        self.wls = np.linspace(6186.767850650795e-10, 6936.550674450071e-10, 70)

    def B(self,wl,T):
        a = 2.*h*c**2
        b = (h*c)/(wl*k*T)
        ans = a/((wl**5)*(np.exp(b)-1.))
        return ans

    def plot(self):
        xs = self.wls*1e9
        ys = self.B(self.wls,self.T)
        plt.plot(xs,ys,label=f'{self.name}')
        plt.ylabel(r"Radiance $\frac{W}{m^2sr}$")
        plt.xlabel(r"Wavelength (nm)")
        plt.title(r"Planck Spectra of Merak")
        #plt.legend()
```

```

def crop_plot(self):
    xs = self.wls*1e9
    ys = self.B(self.wls,self.T)
    x_bound = xs[:] * 10
    y_bound = ys[:] * 10
    return x_bound, y_bound


merak = Planck(9377, 'Merak')

merak.plot()

xcrop, ycrop = merak.crop_plot()

plt.legend()
plt.show()

```



```

In [32]: #Comparing the Merak spectra with the theoretical Planck spectra


s = 1.53e12

plt.plot(xcrop,ycrop/s,label='Blackbody')
plt.plot(wavelength_axis, merak_tot,label='Observed')
plt.xlabel(r'Wavelength ($\AA$)')
plt.title('Theoretical Blackbody Distribution with Observed Merak Spectrum')
plt.legend()

```


Out[32]: <matplotlib.legend.Legend at 0x7f79b0b39fd0>

Theoretical Blackbody Distribution with Observed Merak Spectrum



```
In [33]: scales = ycrop / total_points

merak_tot_scaled = merak_og * scales
plt.plot(wavelength_axis, merak_tot_scaled)
plt.title("Emission Spectra of Merak")
plt.ylabel(r"Radiance  $\frac{W}{m^2sr}$ ")
plt.xlabel(r"Wavelength (nm)")
plt.show()
```



## Sky

```
In [34]: sky_spec = fits.open('calibrated_fits_files/sky_mean.000.FIT')

sky_spec_data = sky_spec[0].data


sky_crop = sky_spec_data[30:100,:]

#Apply normalized flat field to arc lamp spectrum using the first order fit
science_sky = sky_crop / thirty_normalized_flat_field

# Calculate the 1D spectra by averaging along the y-axis
sky_tot = np.mean(science_sky, axis=0)

# Plot the 1D pixel counts against pixel positions along the dispersion axis
dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, sky_tot)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('Counts')
plt.title('Sky Pixel Spectra')
plt.grid(True)
plt.show()
```



## M51


```
In [35]: from astropy.io import fits
import matplotlib.pyplot as plt
import numpy as np

#One of the M51 FITS
m51_spec = fits.open('calibrated_fits_files/m51_mean.001.FIT')

m51_spec_data = m51_spec[0].data

plt.imshow(m51_spec_data[0], cmap='gray', vmin=-10, vmax=200)
plt.colorbar()
plt.title('M51 Spectra')
```

```
Out[35]: Text(0.5, 1.0, 'M51 Spectra')
```




```
In [36]: #Crop data to only include the top band (50um)

m51_crop = m51_spec_data[0][30:100,:]

plt.imshow(m51_crop,cmap='gray', vmin=-10,vmax=200)
plt.title(r'50$\mu$m Slit Crop')
```

Out[36]: Text(0.5, 1.0, '50\$\mu\$m Slit Crop')



```
In [37]: m51_data = []

# find and open the Flat Fields and store them all in one list
file_prefix = "m51_mean.00"
file_end = ".FIT"
pixel_data = [None]*3

for i in range(0, 3):
    filename = file_prefix + str(i) + file_end
    print(filename, i)
    list = fits.open('../Lab_3/calibrated_fits_files/'+filename)
    image_data = list[0].data
    pixel_data[i] = image_data[0][30:100,:]

# open a 2d list to store median values
m51_median_values = np.zeros((70, 765))
```

```
# run through and calculate the median value for each pixel
for i in range(0, 70):
    for j in range(0, 765):
        values = [pixel_data[x][i][j] for x in range(0,3)]
        m51_median_values[i][j] = np.mean(values)
```

m51\_mean.000.FIT 0

m51\_mean.001.FIT 1


m51\_mean.002.FIT 2

```
In [38]: #Apply normalized flat field to arc lamp spectrum using the first order fit
science_m51 = m51_median_values / thirty_normalized_flat_field

# Calculate the 1D spectra by averaging along the y-axis
m51_tot = np.mean(science_m51, axis=0)

# Plot the 1D pixel counts against pixel positions along the dispersion axis
dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, m51_tot)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('Counts')
plt.title('1D M51 Pixel Spectra')
plt.grid(True)
plt.show()
```



```
In [39]: # Using best fit equation, adjust x-axis from pixels to nm

testm51 = m51_tot - sky_tot
plt.plot(wavelength_axis, m51_tot*scales)
plt.xlabel(r'Wavelength ($\AA$)')
```

```

plt.ylabel(r"Radiance  $\frac{W}{m^2 sr}$ ")
plt.title('M51 Emission Line Spectra')

#Add labels for stronger emission lines
#plt.text(584,530,'588nm',color='red',alpha=1.0,fontsize=9.5)

plt.grid(True)
plt.show()


plt.plot(wavelength_axis, m51_tot*scales)
plt.xlabel(r'Wavelength ( $\text{\AA}$ )')
plt.ylabel(r"Radiance  $\frac{W}{m^2 sr}$ ")
plt.title('M51 Emission Line Spectra')

peaks51, _ = find_peaks(m51_tot, height=150)

print(peaks51)

for p in peaks51:
    print(wavelength_axis[p])
    plt.scatter(wavelength_axis[p], m51_tot[p]*scales[p], c='r')

```




```

[355 399 628]
6535.161702023495
6578.3429117710975
6803.081480684755

```






## M82

```
In [40]: from astropy.io import fits
import matplotlib.pyplot as plt
import numpy as np

#One of the M82 FITS
m82_spec = fits.open('calibrated_fits_files/m82_mean.000.FIT')

m82_spec_data = m82_spec[0].data
plt.imshow(m82_spec_data[0], cmap='gray', vmin = -10, vmax = 200)
plt.colorbar()
plt.title('M82')
```

Out[40]: Text(0.5, 1.0, 'M82')



```
In [41]: m82_data = []

# find and open the Flat Fields and store them all in one list
file_prefix = "m82_mean.00"
file_end = ".FIT"
pixel_data = [None]*3

for i in range(0, 3):
    filename = file_prefix + str(i) + file_end
    print(filename, i)
    list = fits.open('../Lab_3/calibrated_fits_files/'+filename)
    image_data = list[0].data
    pixel_data[i] = image_data[0][30:100,: ]

# open a 2d list to store median values
m82_median_values = np.zeros((70, 765)) #the cropped image is a 125 x 765 pixel

# run through and calculate the median value for each pixel, 125 for y-axis and
for i in range(0, 70):
    for j in range(0, 765):
        values = [pixel_data[x][i][j] for x in range(0,3)]
        m82_median_values[i][j] = np.median(values)

m82_mean.000.FIT 0
m82_mean.001.FIT 1
m82_mean.002.FIT 2
```

```
In [42]: #Apply normalized flat field to arc lamp spectrum using the first order fit
science_m82 = m82_median_values / thirty_normalized_flat_field

# Calculate the 1D spectra by averaging along the y-axis
m82_tot = np.mean(science_m82, axis=0)


# Plot the 1D pixel counts against pixel positions along the dispersion axis
```

```

dispersion_axis = np.arange(765)

plt.plot(dispersion_axis, m82_tot)
plt.xlabel('Pixel Positions Along Dispersion Axis')
plt.ylabel('Counts')
plt.title('1D M82 Pixel Spectra')
plt.grid(True)
plt.show()

```



In [45]: *# Using best fit equation, adjust x-axis from pixels to nm*

```

plt.plot(wavelength_axis, m82_tot*scales)
plt.xlabel(r'Wavelength ($\AA$)')
plt.ylabel(r'Radiance $\frac{W}{m^2sr}$')
plt.title('M82 Emission Line Spectra')

#Add labels for stronger emission lines
#plt.text(584,530,'588nm',color='red',alpha=1.0,fontsize=9.5)


plt.vlines(x=6562,ymin=0,ymax=500,color='green')
plt.grid(True)
plt.show()

plt.plot(wavelength_axis, m82_tot*scales)
plt.xlabel(r'Wavelength ($\AA$)')
plt.ylabel(r'Radiance $\frac{W}{m^2sr}$')
plt.title('M82 Emission Line Spectra')
peaks82, _ = find_peaks(m82_tot, height=200)


print(peaks82)

```

```
for p in peaks82:  
    print(wavelength_axis[p])  
    plt.scatter(wavelength_axis[p], m82_tot[p]*scales[p], c='r')
```



```
[355 399 628]  
6535.161702023495  
6578.3429117710975  
6803.081480684755
```



In [44]: *# Here we're going to fit gaussians to our peaks to find the uncertainty in our*

```
from astropy.modeling import models, fitting

maxs = [355, 399, 628]
data = [m51_tot, m82_tot]
k = 0


for sets in data:
    for i in range(0, 3):
        r = sets[maxs[i]-10:maxs[i]+11]
        y1s = r[:5]
        y2s = r[16:]
        for j in range(len(y1s)):
            if y1s[j] >= 0.25*np.max(r):
                y1s[j] = np.mean(y1s)
            if y2s[j] >= 0.25 * np.max(r):
                y2s[j] = np.mean(y2s)

        ys = np.hstack((y1s, r[5:16], y2s))
        xs = wavelength_axis[maxs[i]-10:maxs[i]+11]


        amp = np.max(ys)
        mu = np.median(xs)
        g = models.Gaussian1D(amplitude=amp, mean=mu) + models.Const1D()
        fitter = fitting.LevMarLSQFitter()
        g_fit = fitter(g, xs, ys)
        amp, mean, stddev, c = g_fit.parameters
        x_values = np.linspace(xs[0], xs[-1], 1000)
        y_values = g_fit(x_values)
```

```
print(f"The stddev of the gaussian is {stddev:.4f}")
if k == 0:
    plt.title(rf"M51: Peak at {mean:.2f} $\AA$")
elif k == 1:
    plt.title(rf"M82: Peak at {mean:.2f} $\AA$")
plt.plot(xs, ys)
plt.plot(x_values, y_values)
plt.show()
k += 1
```


The stddev of the gaussian is 0.2730




The stddev of the gaussian is 0.3081




The stddev of the gaussian is 0.1238



The stddev of the gaussian is 0.1208



The stddev of the gaussian is 0.3143



The stddev of the gaussian is 0.2277



